


eCLIPS™



ENGLISH



Capacity: 5000g / 11lb:0.4oz / 5000ml / 176.4fl.oz

Accuracy: 1g / 0.1lb:oz / 1ml / 0.1fl.oz

Thank you for purchasing the My Weigh® ECLIPS™ digital scale. Please read all operating instructions carefully before use. This electronic scale is a precision instrument. With normal care and proper treatment, it will provide years of reliable service. For more information please visit www.myweigh.com

Never load the scale with more than the maximum capacity. Although the ECLIPS™ is designed to be extremely durable with extra overload protection built into the case, overloading will permanently damage it! Avoid any exposure to extreme heat or cold, your scale works better when operated at normal room temperature. Keep your scale in a clean environment. Dust, dirt, moisture, vibration, air currents and/or a close proximity to other electronic equipment can all cause an adverse effect on the reliability and accuracy of your scale. Handle with care. Gently apply all items to be weighed onto tray top. Avoid shaking, dropping or otherwise shocking the scale. Scales are delicate instruments and unlike cellular phones, scales have delicate sensors that determine how much an item weighs. If you drop or shock your scale, these sensors “feel” the shock and are sometimes destroyed. This happens with all digital scales. We design our scales to be as resistant to shock or drops as possible, however there is no way for us to protect 100% against load cell or sensor damage.

Failure to follow these instructions will void your warranty.

Always allow the scale to acclimate to normal room temperature for at least one hour before use. Give your scale sufficient warm up time. Usually 30-60 seconds before calibration to give the internal components a chance to stabilize.

PRECAUTIONS BEFORE USING THE BALANCE

1. Do not overload the scale in order to protect the sensor from damages.
2. Items should always be placed on the center of the platform when being weighed.
3. Do not drop or shock the scale.
4. Clean the scale with a damp cloth, DO NOT immerse the scale in water or use chemical/abrasive cleaning agents.

BATTERIES

Low Batteries & bad battery connections are the #1 cause of scale malfunction and inaccuracy! We test all of our scale returns from consumers and 60% of them are battery related problems. This sounds silly but it's true! A scale will perform poorly when it has low batteries. Use good quality batteries & replace them often (Remove the batteries if you plan to store the scale for longer than 14 days). We include good quality batteries with all of our scales but they can run low in storage. If your scale simply won't turn on while on battery power, it is often caused by loose battery connections.



Battery installation

- a) Press and lift open the battery cover located at the bottom of the unit.
- b) Insert the batteries and make sure the polarity is correct.
- c) Close the battery cover until it clicks shut.

Note : If the battery symbol appears in the display, it means low battery power. It is time to replace the batteries.

OPERATION INSTRUCTIONS




Weighing Procedures

1. Press [] to turn on the scale.
2. Press [MIN/UNIT] to select a weighing unit g, oz , ml, fl:oz
3. Start weighing
4. To turn off the scale, press and hold [] for 3 seconds

Tare

Tare can be used for eliminating the weight value of an empty container. Place an empty container on the scale and press [TARE]. After 3 seconds place the items to be weighed in the container. NOTE: When all weight is removed from the weighing tray, the tared value of a container will be displayed as a negative number. Press [TARE] again to return the scale to zero.

TIMER

1. Press [] to turn on the timer.
2. Press [MIN/UNIT] to set the minute value, press [SEC] to set the second value.
3. Next press [] to start or stop the timer.
4. If you want to reset the timer, press [] for 2 seconds.

Auto OFF

The scale will automatically turn off after 30 seconds of non use.

SPECIFICATIONS

Capacity	5000g x 1g	Units	g, oz , ml, fl:oz
Scale dimension	242 x 168 x 28mm (9.5"x 6.6"x 1.1")		
Scale Weight	590 g (20.8oz)		
Operating temperature	Optimum 10-40°C (50-104°F)		
Power Source	3 x AAA Batteries		
Tare range	Up to scale's maximum capacity		

