




MyWeigh®




élite[™]

USER MANUAL

élite™



ENGLISH



Capacity
180kg x 0.1kg
400lb x 0.2lb
28.6st

Thank you for purchasing the My Weigh® Elite™ digital scale. Please read all operating instructions carefully before use. This electronic scale is a precision instrument. With normal care and proper treatment, it will provide years of reliable service. For more information please visit www.myweigh.com.

Never load the scale with more than the maximal capacity. Although the scale is designed to be extremely durable with extra overload protection built into the case, overloading will permanently damage it! Avoid any exposure to extreme heat or cold, your scale works better when operated at normal room temperature. Keep your scale in a clean environment. Dust, dirt, moisture, vibration, air currents and/or a close proximity to other electronic equipment can all cause an adverse effect on the reliability and accuracy of your scale. Handle with care. Gently apply all items to be weighed onto tray top. Avoid shaking, dropping or otherwise shocking the scale. Scales are delicate instruments and unlike cellular phones, scales have delicate sensors that determine how much an item weighs. If you drop or shock your scale, these sensors "feel" the shock and are sometimes destroyed. This happens with all digital scales. We design our scales to be as resistant to shock or drops as possible, however there is no way for us to protect 100% against load cell or sensor damage. Failure to follow these instructions will void your warranty.

OPERATING INSTRUCTIONS

- Before using the scale for the first time, check the battery compartment and remove any plastic insulation strips or packaging that may be in place to prevent battery drainage during shipping / storage.
- Step on the center of the scale. The scale turns on and starts weighing. Once stable, the numbers will flash and then lock.
- To change the units press the key at the bottom of the scale. It is possible to change between kg/lb/st.
- If the display indicates "Lo" when the scale starts, it means the battery needs to be replaced.
- If the display indicates "Err", it means there is something wrong with the operation. Please restart the weighing process.

REMINDER

- Do not use the scale on carpet.
- Keep the scale dry and away from water.
- Do not overload the scale in order to protect the sensor from damages.
- Avoid movements when standing on the platform to ensure a precise reading.
- Stand in the center of the scale to prevent slipping.
- Do not drop or shock the scale.
- Clean the scale with a slightly damp cloth, DO NOT immerse the scale in water or use chemical/abrasive cleaning agents.

Capacity	180kg x 0.1kg 400lb x 0.2lb 28.6 st,lb	Units	kg, lbs, st,lb
Minimal weight	3kg		
Power source	2 x CR2032		
Auto-off	10 seconds		
Working temp.	10° C - 35° C		

